

ZoneMaster PRO range

AC panel transient voltage surge suppressors

Introduction

This document explains how to install the ZoneMaster PRO AC panel surge protection devices.

Installation instructions

Warning: Terminals marked L1, L2, L3, N, GND (where relevant) must be connected respectively to phase(s) neutral and ground. Failure to comply may result in personal injury or equipment damage. See corresponding diagrams for proper connections.

Installation description

ZoneMaster PRO units are connected in parallel ("shunt") across the supply to be protected. The connecting cable does not carry the supply current, only the current associated with suppressing the transient overvoltage.

Mounting

The unit should be mounted as close as possible to the panel to be protected. Conduit, preferably metallic, is to be installed from the suppressor to the panel. Determine a location where the connection wires will be installed and then drill a suitable hole in the ZoneMaster PRO enclosure.

IMPORTANT

Incorrect installation will impair the effectiveness of the AC panel protectors.

Connecting leads

Connect the suppressor as shown in the installation diagram. Connect the terminals within the suppressor to the load side of 60A breakers or fuses within the panel. See specific connection diagrams for more details and markings on unit if provided.

Recommended wire gauge - stranded copper

Minimum of 8 AWG
Maximum of 4 AWG (for ease of dressing)
Torque Rating: 35- 50 in- lbs.

Length of connecting leads

The longer the connecting leads between the ZoneMaster PRO and power panel, the higher the residual transient voltage.

RECOMMENDED MAXIMUM: 500mm (19")

IDEALLY: 250mm (10")

Each 250mm increase in cable length increases clamping voltage by 25V per 1000A surge current discharged.

IMPORTANT

- Bind the phase, neutral and ground conductors tightly, over the entire run from the suppressor to the service panel.
- Always use the shortest length of connecting cable possible.

Connection



WARNING:

Verify that all power circuits are de-energized and locked out before making electrical connections.

Before making connections to the unit, verify that the ZoneMaster PRO service rating is appropriate for connection to the intended electrical service. Each ZoneMaster PRO has terminal lugs that are marked L1, L2, L3, N and G where appropriate. See figures 1, 2 or 3, depending on the model of the ZoneMaster PRO.

Surge counter CT

Any wire can be inserted through the "CT". The most common installations are through the neutral or ground wires.



WARNING:

Connect the high-leg or wild-leg to terminal L2 when installing the unit on a high-leg delta electrical service. Mis-installation will cause the suppressor to fail upon power-up.

Connecting the SPD to the bus in the switchgear or MCC:

Connect #2AWG to #6AWG ground and neutral (if applicable) conductors between the buss bar lugs in the SPD to the ground and neutral busses in the switchboard. Connect the phase conductors to the SPD buss bar terminals and/or disconnect with the appropriate size conductors. SPD's that do not utilize an internal disconnect must be provided with a means of removing power to the device for servicing. It is important to keep all connecting leads as short as possible. Additionally, conductors should be twisted together for as much of the wire run as possible. If larger phase conductors are specified, a molded case circuit breaker that can utilize the larger cables must be supplied as an option.

Installation diagrams




Figure 1

120/208V Three Phase 4W WYE
120/240V Three Phase 4W DELTA (HL = L2)
277/480V Three Phase 4W WYE
240/415V Three Phase 4W WYE
220/380V Three Phase 4W WYE




Figure 2

120/240V Split Phase 3W




Figure 3

TROUBLESHOOTING/REPAIR



WARNING:

Only qualified personnel should perform maintenance on this unit. Hazardous voltages are present inside the unit during normal operations. Electrical safety precautions must be followed when servicing this unit. To prevent risk of electrical shock, turn off and lock out all power sources to the unit before servicing.

Remove the cover and determine which module has failed by reviewing the LED status indication window (see page 7 'Status Indicators') then disconnect the power. Next, disconnect the remote monitoring plug located on top of the module. Then use a 7/16" socket wrench or nutdriver to remove the nuts that hold the module in place. Replace module with same type and color code. Replace nuts and tighten securely. DO NOT OVERTIGHTEN. Insert remote monitoring plug. Install cover, restore power and check for normal operation.

Units with internal disconnect

The disconnect handle is mounted to the inside of the enclosure cover. Slide it from the tie-wraps and insert square end into disconnect switch. When complete, remove handle from switch and slide it back into place on the cover. Reinstall enclosure cover.

External handled disconnect units

Located on the cover is the LED status indication of each module (see page 7 'Status Indicators'). Determine which module has failed then disconnect power and remove the cover. Next, disconnect the remote monitoring plug located on top of the module. Then use a 7/16" socket wrench or nutdriver to remove the nuts that hold the module in place. Replace module with same type and color code. Replace nuts and tighten securely. DO NOT OVERTIGHTEN. Insert remote monitoring plug. Install cover, restore power and check for normal operation.

Setting surge monitor modes of operation

The following is displayed upon power-up and when in monitor mode. To change monitor options, push the mode button. This will step through the different program modes. To reset the surge count, hold down both the mode and select buttons for about 5 seconds. The count will be set to zero.

M	o	n	i	t	o	r		M	o	d	e				
S	u	r	g	e	C	o	u	n	t	=	0	0	0	0	0

Program mode - Alarm

P	r	o	g	r	a	m		M	o	d	e				
A	l	a	r	m	=	O	N								

- ON:** The surge monitor will detect the module status and display "Module Failure" if a module fails.
- OFF:** The surge monitor does not give a module status and the audio option is disabled.

WARNING:
If remote monitoring from a different source is desired, the alarm option must be set to OFF and the connector on the surge monitor disconnected. Failure to do so will cause damage to the surge monitor and possibly to the connected monitoring

Program mode - Audio

P	r	o	g	r	a	m		M	o	d	e				
A	u	d	i	o	=	O	N								

- ON:** The alarm will sound for about 2 seconds if a surge is detected. If a module fails the alarm will sound continuously until either the mode or select button is pushed
- OFF:** No alarm is sounded and only the display will indicate that a module has failed or a surge was detected.

Program mode- Sensitivity

(Typical 8/20 μ s impulse)

P	r	o	g	r	a	m		M	o	d	e				
S	e	n	s	i	t	i	v	i	t	y	=	2	0	0	A

Display will read- *200A or *500A


*Level at which counter will register a surge count.

Press mode again to return to monitor mode.

Operation

The ZoneMaster PRO Series Surge Protection System requires little or no operator intervention after installation. The units are provided with a multi-mode surge monitor that provides fault status (audible and visual) and a surge counter that counts how many transients the unit has suppressed.

Normally the counter displays the number of surges counted. In the event of a module failure, the display changes to MODULE FAILURE and an audible alarm will sound. See page 5 for trouble shooting/repair.



Status indicators

The ZoneMaster PRO units have comprehensive, continuous visual status monitoring present on each module.

Power/Protection indicator

Remote indicators

A remote indication of the reduced protection state is available as a normally open or normally closed dry contact "Form C". Rated maximum 1A at 30Vdc resistive and maximum 0.3A at 125Vac (30VA dc or 37.5VA ac) general use. Suitable for connection of AVLV2 18AWG to 20AWG copper wire. Recommended tightening torque: 7 in- lbs.



Routing of these wires should be separate from the power with a minimum of spacing of two inches.



WARNING

Of high neutral to ground voltage on certain models, if both red and green lights are on, consult a qualified electrical contractor to check the integrity of the building wiring.

Recommended cable dressing



THIS PAGE IS LEFT INTENTIONALLY BLANK

AUSTRALIA

MTL Instruments Pty Ltd,
10 Kent Road, Mascot, New South Wales, 2020, Australia
Tel: +61 1300 308 374 Fax: +61 1300 308 463
E-mail: mtl-salesanz@eaton.com

BeNeLux

MTL Instruments BV
Ambacht 6, 5301 KW Zaltbommel
The Netherlands
Tel: +31 (0) 418 570290 Fax: +31 (0) 418 541044
E-mail: mtl-benelux@eaton.com

CHINA

Cooper Electric (Shanghai) Co. Ltd
955 Shengli Road, Haigang Industrial Park
Pudong New Area, Shanghai 201201
Tel: +86 21 2899 3817 Fax: +86 21 2899 3992
E-mail: mtl-cn@eaton.com

FRANCE

MTL Instruments srl,
7 rue des Rosières, 69410 Champagne au Mont d'Or
France
Tel: +33 (0)4 37 46 16 53 Fax: +33 (0)4 37 46 17 20
E-mail: mtlfrance@eaton.com

GERMANY

MTL Instruments GmbH,
Heinrich-Hertz-Str. 12, 50170 Kerpen, Germany
Tel: +49 (0)22 73 98 12-0 Fax: +49 (0)22 73 98 12-2 00
E-mail: cskkerpen@eaton.com

INDIA

MTL India,
No.36, Nehru Street, Off. Old Mahabalipuram Road
Sholinganallur, Chennai- 600 119, India
Tel: +91 (0) 44 24501660 / 24501857 Fax: +91 (0) 44 24501463
E-mail: mtlindiasales@eaton.com

ITALY

MTL Italia srl,
Via San Bovio, 3, 20090 Segrate, Milano, Italy
Tel: +39 02 959501 Fax: +39 02 95950759
E-mail: chminfo@eaton.com

JAPAN

Cooper Crouse-Hinds Japan KK,
MT Building 3F, 2-7-5 Shiba Daimon, Minato-ku,
Tokyo, Japan 105-0012
Tel: +81 (0)3 6430 3128 Fax: +81 (0)3 6430 3129
E-mail: mtl-jp@eaton.com

NORWAY

Norex AS
Fekjan 7c, Postboks 147,
N-1378 Nesbru, Norway
Tel: +47 66 77 43 80 Fax: +47 66 84 55 33
E-mail: info@norex.no

RUSSIA

Cooper Industries Russia LLC
Elektrozavodskaya Str 33
Building 4
Moscow 107076, Russia
Tel: +7 (495) 981 3770 Fax: +7 (495) 981 3771
E-mail: mtlrussia@eaton.com

SINGAPORE

Cooper Crouse-Hinds Pte Ltd
No 2 Serangoon North Avenue 5, #06-01 Fu Yu Building
Singapore 554911
Tel: +65 6 645 9864 / 5 Fax: +65 6 487 7997
E-mail: sales.mtlsing@eaton.com

SOUTH KOREA

Cooper Crouse-Hinds Korea
7F Parkland Building 237-11 Nonhyun-dong Gangnam-gu,
Seoul 135-546, South Korea
Tel: +82 6380 4805 Fax: +82 6380 4839
E-mail: mtl-korea@eaton.com

UNITED ARAB EMIRATES

Cooper Industries/Eaton Corporation
Office 205/206, 2nd Floor SJ Towers, off. Old Airport Road,
Abu Dhabi, United Arab Emirates
Tel: +971 2 44 66 840 Fax: +971 2 44 66 841
E-mail: mtgulf@eaton.com

UNITED KINGDOM

Eaton Electric Limited,
Great Marlings, Butterfield, Luton
Beds LU2 8DL
Tel: +44 (0)1582 723633 Fax: +44 (0)1582 422283
E-mail: mtlenquiry@eaton.com

AMERICAS

Cooper Crouse-Hinds MTL Inc,
3413 N. Sam Houston Parkway W,
Suite 200, Houston TX 77086, USA
Tel: +1 281-571-8065 Fax: +1 281-571-8069
E-mail: mtl-us-info@eaton.com



Eaton Electric Limited,
Great Marlings, Butterfield, Luton
Beds, LU2 8DL, UK.
Tel: + 44 (0)1582 723633 Fax: + 44 (0)1582 422283
E-mail: mtlenquiry@eaton.com
www.mtl-inst.com
© 2016 Eaton
All Rights Reserved
Publication No. INS 801-720 Rev C 041016
October 2016

EUROPE (EMEA):
+44 (0)1582 723633
mtlenquiry@eaton.com

THE AMERICAS:
+1 800 835 7075
mtl-us-info@eaton.com

ASIA-PACIFIC:
+65 6 645 9888
sales.mtlsing@eaton.com

The given data is only intended as a product description and should not be regarded as a legal warranty of properties or guarantee. In the interest of further technical developments, we reserve the right to make design changes.