

Torque supports



WDGDS10001

Torque support WDGDS10001

suitable for thru-bore or hollow bore (blind) encoders (all types). Is provided as standard in the required number with all hollow shaft encoders and end hollow shaft encoders (except WDGA 36E).



WDGDS10004

Torque support WDGDS10004

Torque support for hollow shaft encoders and end hollow shaft encoders (all types, except WDGA 36E).



WDGDS10007

Torque support WDGDS10007

Torque support for hollow shaft encoders and end hollow shaft encoders (all types, except WDGA 36E).



WDGDS10008

Torque support WDGDS10008

for hollow shaft encoders and end hollow shaft encoders (all types, except WDGA 36E).



WDGDS10009

Torque support WDGDS10009

Torque support for hollow shaft encoders and end hollow shaft encoders (all types, except WDGA 36E).



WDGDS10012

Torque support WDGDS10012

for hollow shaft encoders and end hollow shaft encoders (all types, except WDGA 36E).



WDGDS10013

Torque support WDGDS10013

for hollow shaft encoder WDGI 58H.



WDGDS10003

Torque support WDGDS10003

for hollow shaft encoders and end hollow shaft encoders (all types, except WDGA 36E).



WDGDS10011

Torque support WDGDS10011

for hollow shaft encoders and end hollow shaft encoders
(all types, except WDGA 36E).



WDGDS10016

Torque support WDGDS10016

for hollow shaft encoder WDGA 36E with hollow shaft (blind) Ø 6 mm.



WDGDS10019

Torque support WDGDS10019

for hollow shaft encoder WDGI 58H, WDGI 58E and WDGA 58E.



WDGDS10020

Torque support WDGDS10020

Torque support for hollow shaft encoders and end hollow shaft encoders
(all types, except WDGA 36E).
